

CP-N4 STARTER COMBO

STARTER HEADLIGHT

SL-150

MODE	LUMEN	RUNTIME
------	-------	---------

Steady	150	up to 30 hrs
--------	-----	--------------

Flashing	—	up to 85 hrs
----------	---	--------------

WEIGHT	133g with bracket	
---------------	-------------------	--

DURÉE CONFIGURATION	Jusqu'à 85 heures Modes constant et clignotants.	
----------------------------	--	--

DAUER KONFIGURATION	Bis zu 85 Stunden Verlässliche und blinkende Modi.	
----------------------------	--	--

DURACIÓN CONFIGURACION	Hasta 85 horas Modos intermitentes y constantes.	
-------------------------------	--	--

ATTENTION

When charging the front light

- 1 Hold light with on/off button facing you with lens up.
- 2 Holding the lower body with one hand, lightly twist head portion from left to right.
- 3 Remove battery holder and replace batteries.
- 4 Put head back on and twist from right to left to secure.

- Includes: Mounting Bracket & (3) AAA Batteries

International Consumers

Please contact your local distributors for warranty guidelines as they may vary by country. List of distributors can be found at serfas.com/sitemap/view/8.



WARNING

This product may contain a chemical known to the State of California to cause cancer, birth defects, or other reproductive harm.

SERFAS, INC.

2333 W. Utopia Rd.
Phoenix, AZ 85027

serfas.com

3-LED REAR FLASHER TAIL LIGHT

TL-415

MODE	LUMEN	RUNTIME
------	-------	---------

Steady	3	up to 140 hrs
--------	---	---------------

Flashing	—	up to 200 hrs
----------	---	---------------

WEIGHT	50g with bracket	
---------------	------------------	--

DURÉE CONFIGURATION	Jusqu'à 200 heures Modes constants et clignotants.	
----------------------------	--	--

DAUER KONFIGURATION	Bis zu 200 Stunden Modi, verlässliche und blinken.	
----------------------------	--	--

DURACIÓN CONFIGURACION	Hasta 200 horas Modos de constantes e intermitentes.	
-------------------------------	--	--

ATTENTION

Tail light battery replacement

- 1 Hold light facing you with on/off switch to the right.
- 2 Holding the black portion of the body, insert coin into left or right notch placed between red/black housing.
- 3 Twist coin to separate casing.
- 4 Input batteries according to +/- configuration. Noted on light body.
- 5 Push body back together.

- Includes: 2(AAA) Batteries, & Handlebar Bracket

Care

*Make sure to clean the dust and dirt on the light with soft damp cloth after every ride.

*Water resistant is for rain water only. Do not submerge the battery or the whole light into water when cleaning.

Warranty

Serfas warrants to the original purchaser of this product that the product is free from defects in material and workmanship for the lifetime of the product. This warranty does not apply to damage due to heat, physical damage (crashing) resulting from abuse, neglect, improper repair, improper fit, or alterations of the fixture. This warranty is in lieu of all other agreements and warranties, general or specific, express or implied and no representative or person is authorized to assume liability on behalf of Serfas in connection with the sale and use of this product.

Serfas reserves the right to request the return of any product submitted for warranty consideration. All customers should contact Serfas directly for warranty service.

To make a claim, please e-mail warranty@serfas.com.