



TL-200 Specification Chart

Mode	Lumen	Runtime [hrs:min]
Steady	30	Up to 22:00
Flashing	...	Up to 80:00
Alt Flash	...	Up to 80:00
Weight (grams)		88g With Bracket

Durée: Jusqu'à 80 heures
Configuration: Élevé, moyen, faible, clignotant

Voir à l'intérieur de la boîte pour obtenir des instructions supplémentaires.

Dauer: Bis zu 80 Stunden
Konfiguration: Hoch, Mittel oder niedrig, blinken

Finden Sie im Strafraum weitere Anweisungen.

Duración: Hasta 80 horas
Configuración: Alto, medio, bajo, intermitente

Ver dentro de la caja para instrucciones adicionales.

TAIL LIGHT BATTERY REPLACEMENT

1. Hold light with on/off switch facing towards you.
2. Holding the black portion of the body, insert coin into corner notch between red/black body.
3. Twist coin to separate casing.
4. Input batteries according to +/- configuration. Noted on light body.
5. Push body back together.

- Includes: 2 (AAA) Batteries, Tail Light Bracket.



International Consumers:

Please contact your local distributors for warranty guidelines as they may vary by country. List of distributors can be found at serfas.com/sitepages/view/8.

SERFAS, INC.
2333 W. Utopia Rd.
Phoenix, AZ 85027
Serfas.com

