

TL-STN

Seat Stay Taillight

TL-ST INSTRUCTIONS

- 1 Mount light onto seat stay or seat post by stretching silicone straps around and securing on hook.
- 2 Press power button to power on, switch modes, and power off.

BATTERY REPLACEMENT (2x Lithium CR2032 3v batteries)

- 3 To replace battery, use a coin or large screwdriver to remove battery cover from the back of light unit.
- 4 Remove old batteries and install new batteries with positive "+" pole facing outwards.
- 5 Replace battery cover and turn to original position to secure.

