



## HOW TO UNLOCK

- 1 Slide plastic key dust cover to the side.
- 2 Insert key and turn clockwise.
- 3 Remove shackle.

## HOW TO LOCK

- 1 With key engaged insert shackle.
- 2 Turn key counter clockwise.
- 3 Remove key and slide plastic key dust cover over.

