

UPDATED/NEWER MODEL INSTRUCTIONS

* NEW STYLE UTILIZES MORE USER FRIENDLY U-SHAPED COMBINATION RESET LEVER

STRAIGHT COMBINATION LOCK

CL-20

Arrow Indicators



Reset Lever

1.



HOW TO SET The original code is 0-0-0-0-0. To set your own combination, please follow these steps:


1. Set all digits to 0 to open lock. (Fig. 1)
2. Lift Reset Lever up. Turn dials to set desired combination to the Arrow Indicators (Fig. 2).
3. Pull Reset Lever down (Fig. 3). Close lock to complete. Combination is now set.

2.

Lift Reset Lever.



Create Combination



3.



Pull Reset Lever down and close lock to activate.

HOW TO USE

1. Dial your 5-digit code to the Arrow Indicators. Pull cable out of lock housing to open lock.
2. Insert cable back into the lock housing. Turn dials and scramble to activate lock.

OLDER STYLE MODEL INSTRUCTIONS

* OLD STYLE UTILIZES BARREL STYLE COMBINATION RESET OPERATION

HOW TO SET

The default code is 0-0-0-0. To set your own combination, please follow these steps:

- 1 Open the lock, slide the reset button (1) 90° from Fig.1 position to Fig. 2 position.
- 2 Turn the dials (2), to set your own combination to the convex line (Fig.2).
- 3 Push the reset button (1) back to Fig.3 position. Then the setting is completed, you can open the lock with your new combination.

HOW TO USE

- 1 Dial your passwords to the convex line in the window, pull the cable out of the lock housing, the lock is opened.
- 2 Insert the cable back into the lock housing, turn the dials to scramble the numbers, then the lock is closed.



Fig .1




Fig .2




Fig .3

